

QUALICA-RD 66

Handheld Computer

Accessories Guide



Standard Accessories

Adapter



PWR-RD66-5V2A-CN



PWR-RD66-5V2A-EU



PWR-RD66-5V2A-UK



PWR-RD66-5V2A-US

Adapter (CN/EU/UK/US), I/P; 100-240V, O/P; 5V2A, use with DC-BK-TypeC cable

QC Adapter



PWR-18W-CN



PWR-18W-EU



PWR-18W-UK



PWR-18W-US

Quick Charge adapter (CN/EU/UK/US), I/P; 100-240V, O/P; 5V3A/12V1.5A/9V2A, use with DC-BK-TypeC cable

Comment: standard adapter and QC adapter are alternative.

USB Cable



DC-BK-TypeC
1.0 meter Type-C cable

Battery



BTRY-RD66-43MA
4300mAh Li-ion battery, 3.8 output

Optional accessories

Rugged Rubber Boot



**RB-RD66-RR/
RB-RD66-RRP**
Rugged Rubber Boot only, omni-directional protected. RB-RD66-RR does not support charging cradle. RB-RD66-RRP is pre installed with Type C & Pogo Pin I/O connector, then it supports CRD-RD66-RBC/CRD-RD66-RBCE charging cradle.



**RB-RD66-RRH/
RB-RD66-RRHP**
Rugged Rubber Boot with hand strap, omni-directional protected. RB-RD66-RRH does not support charging cradle. RB-RD66-RRHP is pre installed with Type C & Pogo Pin I/O connector, then it supports CRD-RD66-RBC/CRD-RD66-RBCE charging cradle.




**RB-RD66-RRC/
RB-RD66-RRCP**
Rugged Rubber Boot with belt clip, omni-directional protected. RB-RD66-RRC does not support charging cradle. RB-RD66-RRCP is pre installed with Type C & Pogo Pin I/O connector, then it supports CRD-RD66-RBC/CRD-RD66-RBCE charging cradle.



RB-RD66-P
Type C & Pogo Pin I/O Connector, to be mounted with the rugged rubber boot, enable it to support charging cradle (CRD-RD66-RBC/RBCE). The wired network is available when the rugged rubber bot is placed on the cradle (CRD-RD66-RBCE).

Charging Cradles & Adapters



CRD-RD66-SCC
Charging Cradle for device only, use with DCPWR-12V2A-XX adapter.



CRD-RD66-MBC
Charging Cradle for main battery, up to 4 slots, use with DCPWR-12V2A-XX adapter.



CRD-RD66-PBC
Charging Cradle for pistol battery, up to 2 slots, use with DCPWR-12V2A-XX adapter.



CRD-RD66-INS



CRD-RD66-RBC



CRD-RD66-RBCE

CRD-RD66-RBC/CRD-RD66-RBCE
Charging Cradle device, use with DCPWR-12V2A-XX adapter. CRD-RD66-RBCE is an advanced CRD-RD66-RBC, w/sync, w/ethernet, w/DC. The cradle cup has an insert that must be removed prior to inserting the RD66 Rugged Boot.



DCPWR-12V2A-XX
Adapter (CN/EU/UK/US), I/P: 100-240V, O/P; 12V2A, DC



CRD-MCB
The based of 4-slots charging cradle set for 4 pieces of cradle, use with DCPWR-12V5A-XX adapter. For load balance, recommendation:
1. 4x cradle for device.
2. 3x cradle for device + 1x cradle for main battery.
3. 2x cradle for device + 1x cradle for main battery + 1x cradle for pistol battery.

Vehicle Cradle



CRD-RD66-VC
Vehicle Charger Cradle, with Type-C, use with DC-BK-TypeC cable. Car holder and car adapter need to be purchased separately.

Rubber Bumper



RB-RD66-PR
Protective rubber bumper, upper and lower 4 pcs M1.6 screws are necessary.

Hand Strap



RB-RD66-HS
Hand strap with buckle 2 pcs M1.6 screws are necessary.

Screen Protector



SP-RD66
Tempered glass screen protector.



RB-RD66-PS
Snap-On Trigger Handle and Rugged Boot Kit, use with optional pistol battery 4 pcs M1.6 screws are necessary.



BTY-RD66-PB
Pistol battery, 5,200 mAh